


# Safety & Instruction Manual M&P°15-22 Rifle





2100 Roosevelt Avenue • Springfield, MA 01104 1-800-331-0852 • Fax: 413-747-3317 www.smith-wesson.com

Copyright © 2019 Smith & Wesson Inc. All rights reserved.

WARNING:
READ THESE
INSTRUCTIONS AND
WARNINGS CAREFULLY.
BE SURE YOU UNDERSTAND THESE
INSTRUCTIONS AND WARNINGS
BEFORE USING THIS FIREARM.
FAILURE TO READ THESE INSTRUCTIONS AND TO FOLLOW
THESE WARNINGS MAY RESULT
IN SERIOUS INJURY OR DEATH
TO YOU AND OTHERS AND
DAMAGE TO PROPERTY.

THIS SAFETY & INSTRUCTION
MANUAL SHOULD ALWAYS
ACCOMPANY THIS FIREARM AND BE
TRANSFERRED WITH IT UPON CHANGE
OF OWNERSHIP OR WHEN PRESENTED
TO ANOTHER PERSON. A COPY OF THE
SAFETY & INSTRUCTION MANUAL IS
AVAILABLE FREE VIA DOWNLOAD AT
WWW.SMITH-WESSON.COM
OR UPON REQUEST FROM:

SMITH & WESSON®
CUSTOMER SUPPORT CENTER
2100 ROOSEVELT AVENUE
SPRINGFIELD, MA 01104

TEL.: 1-800-331-0852, ext. 4125 E-mail: qa@smith-wesson.com

NOTE: The M&P°15-22 Rifle, as sold by Smith & Wesson°, is a rifle. Changes to the configuration of the M&P°15-22 Rifle by the end-user, including but not limited to, the addition of a barrel less than 16″ in length may subject the firearm to classification under the National Firearms Act, which imposes registration, taxes, and other requirements on the owners of such firearms. It is your responsibility to comply with all Federal, state and local laws and regulations regarding the ownership or possession of this firearm and any conversions or additions of any aftermarket accessories that you undertake.

### **TABLE OF CONTENTS**

YOUR SAFETY RESPONSIBILITIES	
SAFE STORAGE AND TRANSPORTATION	7-8
AMMUNITION	
MODEL AND FEATURES IDENTIFICATION	12
INSPECTING YOUR RIFLE	
PREPARATION FOR FIRING	
LOADING	
FIRING	17-18
CLEARING MISFIRES	
UNLOADING	
DISASSEMBLY/FIELD STRIPPING	
ASSEMBLY	
REAR SIGHT REMOVAL	23
COLLAPSIBLE STOCK WHEN EQUIPPED	
SIGHT ADJUSTMENT	
MAGAZINE	25 <b>-</b> 26
CLEANING AND MAINTENANCE	
PATENT INFORMATION	29
LIMITED WARRANTY	29-31
CONTACT AND SHIPPING FOR SERVICE	
M-LOK® ACCESSORY ADDENDUM	33-39
BATTERY WARNINGS	40

## YOUR SAFETY RESPONSIBILITIES

#### SAFETY IS YOUR NUMBER ONE RESPONSIBILITY!

- At home, in the field, at the range, or anywhere, the first concern of every firearm owner should be safety. Apply the following safety rules in every situation, with any kind of firearm. If you feel uncertain about any operational aspects of your firearm, please contact Smith & Wesson at 1-800-331-0852, ext. 4125 before proceeding with its operation.
- If you are unfamiliar with firearms you should seek formal training before using your rifle.

WARNING: YOU MUST FOLLOW ALL OF THESE SAFETY RULES TO ENSURE THE SAFE USE OF YOUR FIREARM. THE FAILURE TO FOLLOW THE INSTRUCTIONS AND WARNINGS IN THIS MANUAL COULD CAUSE SERIOUS PERSONAL INJURY OR DEATH TO YOU OR OTHERS AND DAMAGE TO PROPERTY.

 As a firearm owner, you accept a demanding responsibility. How seriously you take this responsibility can be the difference between life and death. There is no excuse for careless or abusive handling of your firearm. At all times handle your firearm with intense respect for its power and potential danger.

### YOUR SAFETY RESPONSIBILITIES CONTINUED

- ALWAYS KEEP YOUR FIREARM POINTED IN A SAFE DIREC-TION. Never point a firearm at anyone or anything you do not intend to shoot whether or not it is loaded. This is particularly important when loading, unloading, or field stripping the firearm. ALWAYS control the direction of the firearm.
- ALWAYS TREAT EVERY FIREARM AS IF IT IS LOADED AND WILL FIRE. Do not take anyone's word that the firearm is unloaded always check for yourself. Never pass your firearm to another person until the cylinder or action is open and you visually check that it is unloaded. Keep your firearm unloaded and safely stored when not in use.
- NEVER PLACE YOUR FINGER INSIDE THE TRIGGER GUARD OR ON THE TRIGGER UNLESS YOU INTEND TO FIRE. Ensure that other objects do not touch the trigger.
- ALWAYS BE SURE OF YOUR TARGET AND WHAT IS BEYOND IT. Always be sure of where the bullet will strike and shoot only where there is a safe back stop free of obstructions, water or other surfaces which can cause ricochets. Be sure your bullet will stop behind your target. Bullets can glance off many surfaces like rocks or the surface of water and travel in unpredictable directions with considerable velocity. Do not fire randomly into the sky.
- NEVER CROSS OBSTACLES SUCH AS FENCES OR STREAMS
   <u>WITH A LOADED FIREARM.</u> Always make certain your firearm is
   unloaded before crossing a fence, climbing a tree, jumping a ditch
   or negotiating other obstacles.
- SAFE FIREARM HANDLING IS YOUR PERSONAL RESPONSI-BILITY AT ALL TIMES. Firearms are dangerous and can cause serious injury or death if they are misused or used inappropriately. Safety must be the prime consideration of any one who owns or handles firearms. Accidents are the result of violating the rules of safe firearm handling and common sense. Firearm safety training is available. Contact your firearms dealer, law enforcement agency, local sportsman's club, etc. for availability.
- YOU ARE RESPONSIBLE FOR THE FIREARM AT ALL TIMES.
  In owning a firearm, you must undertake full-time responsibility for your firearm's safety and security. You must protect yourself and all others against injury or death from misuse of the firearm 24 hours a day.
- FIREARM SECURITY IS YOUR RESPONSIBILITY. You must secure firearms safely from children and/or unauthorized users. Your firearm should always be kept unloaded and locked when not in use. A lock has been provided for this purpose. Never assume that the use of this lock is sufficient to safely secure your firearm. You must always evaluate your personal situation and employ the security systems that meet your needs and prevent children and unauthorized users from gaining access to your firearm.