


Instructions

1. *Safety* - All SOG assisted opening knives have a built-in safety. It is designed to give extra protection against accidental blade opening when carried (in your pocket, for example). See info below for operating specific models.

Aegis - The safety switch is on the side of the handle, towards the back of the knife. To open the blade, make sure the safety is down and shows red. It is now ready to open. When you want to keep the blade locked within the handle, just push the button up to engage the safety. When the safety is on the button will show green.



Flash and Trident - The safety switch is on the side of the handle, towards the back of the knife. To open the blade, make sure the safety is up so the button shows red. It is now ready to open. When you want to keep the blade locked within the handle, just push the button down to engage the safety.

Blink, Twitch, and SlimJim - The safety is on the top of the handle, towards the back/spine. To open the blade, make sure the safety is pushed towards the back end of the handle. To engage the safety, push it towards the locking bar.

2. *Pocket Clip* - If the pocket clip is reversible, it is best to change the clip to the opposite side from which your thumb will be opening the blade. This will give your fingers a better hold on the handle.

3. *Opening the Blade* - Start to open the blade using the thumb stud or blade kick. At about 15 degrees of movement S.A.T. will take over to complete opening and lock the blade in the open position.

It might take a little practice to get comfortable with the grasping and opening of your new knife. If the blade is not opening fully, you might be holding your thumb on the thumb stud too long or blocking the opening blade with one of your other fingers. It is best to push the blade open with your thumb behind the thumb stud... not on top of it.

NOTE: FOR YOUR SAFETY, IT IS IMPORTANT THAT YOU KEEP YOUR OTHER HAND AWAY FROM THE BLADE WHILE OPENING.

4. *Closing the Blade* - To close the blade on the Aegis, Trident and Flash pull back the button on the Arc-Actuator, located on the side of the knife near the pivot, and rotate the blade closed with two hands. The blade is now securely inside the handle. If you want extra security push the safety to the locked position.

To close the blade on the Twitch, push on the lockbar and rotate the blade closed with two hands. The blade is now held securely inside the handle. To lock the blade closed, just slide the safety into the locked position.

NOTE: BE SURE TO ALWAYS KEEP YOUR FINGERS CLEAR WHEN CLOSING ANY KNIFE BLADE.

5. *Groove (Trident Only)* - When using the Groove™ in the handle the blade needs to be in the closed and locked position with safety on. To cut cord or webbing, simply pull the material through the Groove in the handle allowing the blade to cut material. For best results the material being cut should be under tension.

General Maintenance

Your knife is made from the finest stainless steel. All stainless steels can rust under certain conditions. Below is some information to help you get the most of your knife.

- After becoming dirty, or after exposure to salt water, perspiration, or chemicals, rinse the product with fresh water, dry completely, and use a high-quality petroleum-based lubricant or anti-rusting agent on all metal surfaces.

- While it is not in use, keep stored in a dry area outside of the sheath to help prevent rust.

- Should rust appear, use a light steel wool pad (000 grit) to buff off rust, then reapply anti-rusting agent.

- Never store your knife in a wet sheath. Never store your knife in a leather case for long periods, as leather-tanning acids might accelerate rusting.

The SOG SlimJim, Aegis, Flash, Trident, Twitch and Blink are registered trademarks of SOG Specialty Knives and Tools, LLC, and covered under the following patent number 6,941,661.

SOG reserves the right to alter or change product information, specifications or prices without notice. Use this product safely and according to your local municipal, state, and federal laws.

SOG's Lifetime Warranty

All SOG Specialty Knives and Tools, LLC, products are guaranteed against defects in workmanship and materials. This guarantee is voided by misuse, abuse, improper maintenance, or alterations of the product, and does not cover normal wear that might occur. All guarantee claims should be sent directly to SOG Specialty Knives and Tools, LLC. U.S. claims should be sent prepaid and insured. International claims should write or call for information. For more lifetime warranty information please visit the SOG website at www.sogknives.com.

SOG SPECIALTY KNIVES AND TOOLS, LLC, RESERVES THE RIGHT TO THE REPAIR OR REPLACE WARRANTY ITEMS AT OUR DISCRETION.

All warranty claims should be directed to the factory and SOG reserves the right to the repair or replacement of the product at our discretion.

Prices, products, specifications, and availability are subject to change.

Assisted Knife Fact:

Unlike switchblades, which are activated by a button-like mechanism in the handle or with the use of gravity, S.A.T.™ only works when you start to manually open the blade out of the handle, using the thumb stud or blade kick. When the blade is closed, it is held securely inside the handle.

SOG Assisted Knife User Manual

Congratulations on becoming a SOG assisted knife owner. You have chosen a truly innovative product with S.A.T.™ (SOG Assisted Technology). Once you start to open the knife, a spring helps to fully open the blade. Please read this short manual to properly operate your SOG assisted knife.



SOG®

KNIVES ★ TOOLS

SOG Specialty Knives & Tools, LLC
6521 - 212th St. SW • Lynnwood WA 98036
(425) 771-6230 phone • (425) 771-7689 fax
www.sogknives.com • info@sogknives.com