

A-BOLT SPRING INSTRUCTIONS

Make certain the rifle is unloaded before starting on this project.
Remove the stock from the rifle.
Locate the pivot pin that holds the trigger in place.
Drive out the pivot pin and push the trigger down.
Remove the original trigger pull spring and replace with the Timney spring of your choice.
The lighter spring should give you a trigger pull of around 2 pounds.
The heavier spring ought to deliver a 3 pound pull.
Cycle the bolt several times to ensure that the rifle works consistently and safely.
Now put the stock back together with the receiver and cycle the bolt several times again.
If everything checks out safely you're now ready to go to the range and test your rifle.