

AR-15 Scorpion Recoil Pistol Grip

Installation Instructions PART# A.5.10.2347, A.5.20.2347, A.5.40.2347

Thank you for purchasing an ATI product!



Pistol Grip Installation

Point the firearm in a safe direction and place the safety in the "on" position. Next pull back the slide, and carefully inspect the chamber and magazine to be sure the firearm is unloaded.

Step #1

Flip the gun over and locate the bolt inside your current grip stock. Loosen the applied screw with a 3/16" standard allen wrench, and begin removing the grip.



Figure 1

Step #2

Continue to remove the grip completely. Be careful to remove the safety selector spring from the grip. Keep both the safety selector spring and grip bolt for later installation.



Figure 2

Step #3

Insert the safety selector spring into the designed hole on the ATI AR-15 pistol grip. Now, slide the pistol grip into place.

Note: Be sure the safety selector spring is aligned into the safety selector detent hole before the pistol grip is fully in place.



Figure 3

Step #4

Insert the grip bolt through the bottom of the grip and tighten using a 3/16" standard allen wrench. Now, slide the Scorpion Pistol Grip Pad back into place on the grip, and tighten the (2) plastite screws using a philips head screwdriver.




Figure 4

Advanced Technology International • Made In the USA • Limited Lifetime Warranty

2733 West Carmen Ave • Milwaukee, WI 53209

Toll Free: 800.925.2522 • Fax: 414.464.3112