Patch Assembly Instructions

DO NOT SLIDE THE PATCH THROUGH THE SLOTTED TIP.


Please read the enclosed instructions before using this gun cleaning system. Failure to read and follow instructions may cause inadequate results.

- 1. Insert slotted tip in a slot in the patch For shotguns only, slide on the patch saver® over the slotted tip.
- 2. Take a pinch on the patch, pinching upward, slide it through the slot in the tip and pull tight. Note: The closer you pinch to the slotted tip, the smaller the swab. See illustration under Proper Patch **Use** for where to pinch to make the proper size swab.
- 3. Tighten the swab by tugging on the top of the patch.









STANDARD ISSUE OF THE **U.S. MILITARY**

Visit otistec.com for instructional videos

and to see our entire product line





CLEANING INSTRUCTIONS

Proper Patch Use

- 2" Cleaning Patches
- Use for 17 25 caliber firearms
- Use small slotted tip

3" Cleaning Patches

- Use for .25 caliber 12/10 gauge firearms
- Use small slotted tip and outer slots in patch for .25 - .27 caliber firearms
- Use large slotted tip and inner slots in patch for .30 - .50 caliber firearms
- Use shotgun slotted tip and inner slots in patch for shotguns
- 3" Panoply Cleaning Patches (not pictured) Heavy duty for large bore firearms
- Recommended for .38 caliber/9MM or larger firearms

Bore Obstruction Removal Instructions:

Obstruction remover(s) may be included to assist in removal of stuck cases, mud, snow, and other bore obstructions.

- 1. Attach the obstruction remover to the end of a Memory-Flex® cable.
- 2. Insert down the muzzle of the barrel.
- 3. Tap the obstruction rapidly to loosen.
- 4. You may need to run a patch to remove any debris the obstruction may have left behind.

Bore Reflector / Flag Safety:

Your cleaning system may include a bore reflector/flag safety. It can be used to illuminate the barrel to check the bore. It also doubles as a flag safety to indicate the firearm is unloaded. Simply insert into the chamber and close the bolt.

Optics Cleaning:

Your cleaning system may contain optics cleaning equipment. Also sold separately (items #240 & #244).

- 1. Apply lens cleaning solution to lens.
- 2. Wipe thoroughly and dry with lens cleaning tissues. Use cotton swabs for hard to reach areas.
- For dirty lenses: wash with soap & water and dry with lens cloth.
- To remove dust only: brush lens gently with lens brush.











INCORRECT

2

Bore Cleaning:

Prior to cleaning, be sure the firearm is unloaded.

- 1. Assemble slotted tip and obstruction remover to Memory-Flex® cable.
- 2. Create a swab for your firearm. Refer to the Patch Assembly Instructions and the Proper Patch Use sections on the reverse side.
- 3. Insert cable, obstruction remover end first, in the chamber and feed out the muzzle. Insert T-handle bar into the obstruction remover. See Note.
- 4. Place a couple drops of solvent on the swab.
- 5. Pull through from Breech-to-Muzzle®.
- 6. Remove the patch and slotted tip and replace with a bore brush.
 - Note: For short actions, you may need to feed the cable from the muzzle to breech and then attach the bore brush, or you can purchase a limited breech brush for .22 caliber (item# FG-321).

MSR/AR Maintenance Tool Set:


Your cleaning system may contain components from the MSR/AR Maintenance Tool Set. These tools are also great on pistols and in-line muzzleloaders. Also sold separately (item #932).

Can be used to clean the hard to reach areas of your firearm. Sunnested uses include:

			lugs and bolt face.	the bolt and bolt	any other flat
	Short AP Brush		-	carrier.	areas.
AR/MSR (modern sporting rifle)	Cleans the locking lugs, bolt, bolt carrier, firing pin & cam pin.	Pistol		Removes fouling from under the extractor, breech face, slide rails, firing pin channel.	Removes fouling from under the extractor, breech face, slide rails,
Pistol	Loosens fouling on the extractor, breech face, slide, slide rails, firing pin channel, recoil spring assembly, magazine floor plate & follower.			and outside of the slide. Lubricates the slide rails and barrel.	firing pin channel, and outside of the slide.
In-Line Muzzleloader	Loosens fouling from breech plug threads and where breech plug rests.	In-Line Muzzleloader		Brushes powder residue from the bolt. Lubricates the breech plug threads.	Removes caked on carbon, gun powder, and grease from previous cleanings.







End

Brush

Lubricates com-

Cleans the locking ponents such as

Scraper

Cleans the bolt

face, bolt, and

Locking Lug

Scraper

AR/MSR

modern

sporting

rifle

- 7. Insert cable, obstruction remover end first, in the chamber and feed out the muzzle. Insert T-handle bar into the obstruction remover
- 8. Pull through from Breech-to-Muzzle®.
- 9. Remove bore brush and replace with slotted tip.
- 10. Create a swab for your firearm (using a new cleaning surface). Refer to the Patch Assembly Instructions and the Proper Patch Use sections on the reverse side.
- 11. Insert cable, obstruction remover end first, in the chamber and feed out the muzzle. Insert T-handle bar into the obstruction remover
- 12. Pull through from Breech-to-Muzzle®.
- 13. Repeat steps 1-12 as necessary until clean.
- Note: For black powder in-line muzzleloaders, be sure to remove the breech plug prior to cleaning.

Male Rod/

Female Rod

Used to extend

the components

for added reach.

Used to extend

the components

for added reach.

Used to extend

the components

for added reach.

Pin Punch

Removes pins on

firearms held

together by a pin

Removes pins on

firearms held

together by a pin

svstem.

svstem.

Straight

Pick

Removes fouling

from any hard to

Removes fouling

from any hard to

Removes fouling

from any hard to

reach area.

reach area

reach area.











Note: Your cleaning system may not include a T-handle or obstruction remover. These items also sold separately.

12GA

<u>BURE BRUSH SIZE SELELTIUN LHART</u>					
RIFLE/PISTOL (8-32 thread)	BRUSH SIZE				
17HMR, .177 CAL., 4.6MM	.17*				
204 LIMITED BREECH, 22 RIM-FIRE - SHORT ACTION, Limited Breech, 10-22	.21+				
204, 22 RIM-FIRE, 219, 22, 222	.22				
223, 243, 25-06, 25, 257, 5.56MM, 5.7MM, 6MM, 6.35MM, 6.5MM	.25				
270, 280, 284, 6.8MM, 7MM	.27				
30, 30-06, 30-30, 303, 308, 300 Win. Mag., 32, 7,62MM, 8MM	.30				
338, 340, 35, 357	.35				
370, 375, 380, 38 PISTOL, 9MM, 9.3MM	.38				
40, 401, 404, 405, 41, 10.75, 10MM	.40				
44, 444, 45, 458	.45				
50 CAL., 12.9MM	.50				
* NOTE: .17 & .21 brushes come with a 5-40 thread					
MUZZLELOADER/RIFLE (10-32 thread)	BRUSH SIZE				
50 CAL.	.50*				
54 CAL.	.54				
58 CAL.	.58				
* NOTE: .50 brush is available with 8-32 thread and 10-32 thread					
5HOTGUN (8–32 thread)	BRUSH SIZE				
.410	410GA				
28	28GA				
20	20GA				
16	16GA				

NONE NULLI CIZE CELECTION CUANT

10./11.