



V-310

**MOTORIZED ZOOM**

Press and hold. Motor will zoom in and out - release button when desired beam is reached.

**LIGHT INTENSITY ADJUSTMENT****ON/OFF**

Light press for momentary. Press to click for constant.



V-210

**MANUAL ZOOM**

Twist to zoom in and out.

**LIGHT INTENSITY ADJUSTMENT****ON/OFF**

Light press for momentary. Press to click for constant.

**FOR INFRARED (IR) MODELS ONLY:**

THIS ITEM IS ITAR CONTROLLED THROUGH THE U.S. DEPARTMENT OF STATE DIRECTORATE OF DEFENSE TRADE CONTROLS (through the International Traffic In Arms Regulations, 22 C.F.R. §§ 120-130) AND CANNOT BE SHIPPED OR CARRIED OUTSIDE THE UNITED STATES WITHOUT COMPLYING WITH U.S. EXPORT CONTROL LAWS AND REGULATIONS, INCLUDING EXPRESS WRITTEN PERMISSION FROM THE U.S. DEPARTMENT OF STATE. THE USE, RESALE, REEXPORT, OR TRANSFER OUTSIDE OF THE U.S. OF ANY INFRARED (IR) PRODUCTS PROHIBITED OR RESTRICTED FOR EXPORT WITHOUT COMPLYING WITH U.S. EXPORT CONTROL LAWS AND REGULATIONS, INCLUDING PROPER EXPORT LICENSING, DOCUMENTATION OR AUTHORIZATION IS STRICTLY PROHIBITED AND MAY RESULT IN CIVIL PENALTIES AND/OR CONSTITUTE A FEDERAL CRIME. VIRIDIAN WILL NOT ASSIST DIRECTLY OR INDIRECTLY WITH EXPORT OF ANY ITAR CONTROLLED PRODUCTS OUTSIDE THE UNITED STATES UNDER ANY CIRCUMSTANCES. RECIPIENT ACKNOWLEDGES AND UNDERSTANDS THAT ALL U.S. EXPORT CONTROL AND CUSTOMS LAWS, INCLUDING ITAR SHALL APPLY INDEFINITELY AND WILL INDEMNIFY AND HOLD VIRIDIAN HARMLESS IN CONNECTION WITH ANY AND ALL COSTS, EXPENSES, CLAIMS, AND LIABILITY OF ANY KIND OR AMOUNT INCURRED BY VIRIDIAN IN CONNECTION WITH ANY ACT OR OMISSION, NEGLIGENCE, OR RECKLESS DISREGARD BY RECIPIENT WITH RESPECT TO VIOLATION OF ALL APPLICABLE EXPORT CONTROL LAWS AND REGULATIONS CONCERNING VIRIDIAN'S IR PRODUCTS.

**WARNING****INFRARED RADIATION**

Risk of eye damage at short distance.

Turn light source off before servicing.

**SAFETY:**

Read these instructions carefully before using the Illuminator for the first time and keep them handy for future references. This Illuminator is not a toy and must not be treated as such. The illuminated LED will generate heat. Due to its high light emission, it is normal if Illuminator heats up after a long run operation, thus your Illuminator could reach a temperature close to 55°C, rated as 100% normal. Do not hold the bezel or lens of an activated Illuminator against any portion of the human body or any material that could be damaged by heat. Never leave the Illuminator unattended when activated. This product contains batteries. Fire and burn injury hazard when handled improperly. Do not try to open or repair the batteries. Do not dismantle, press, prick or short-circuit the outer contacts or circuits. Do not expose the contacts or circuits into fire or water and avoid exposure of Illuminator and batteries to temperatures above 140° F / 60° C.

Due to its high light emission, it is normal if Illuminator heats up after long run operation, this your Illuminator could reach temperatures close to 131° F / 55° C which is normal. Do not leave the Illuminator switched on or unattended. Do not point the light beam at the eyes or any person. This is a very powerful light source and can damage your Illuminator and your retina. Due to risk of fire, overheating and potential explosion of the batteries, do not leave the Illuminator close to a fire, in a vehicle, the sun or in any other places potentially exposed to high temperatures. Leaving the Illuminator in the water could result in damage and a shorter operating life of the product. Do not manipulate the battery under any circumstances. When fumes, smells or overheating are detected, turn off the Illuminator and remove the batteries. If by accident, any battery interior liquid makes eye or skin contact, was with a large amount of water and see immediate medical attention. If the Illuminator leaks any liquid, remove from any heat source immediately. Battery liquids are flammable and can cause product fire or explosion. When corrosion, strange smells overheating or any other malfunction are noticed before using the Illuminator for the first time, do not use it and immediately contact your local technical service. If Illuminator emits any strange smell or shows any kind of anomaly while being used or stored, do not use it again. Never mix lithium with alkaline batteries, batteries of a different brand, age or different state of charge. If using rechargeable Li-ion batteries, recharge the battery to its full capacity when used for the first time. Never use batteries which are not rechargeable for this device. Always follow the manufacturer instructions prior to use. Using the battery in cold weather conditions shortens running time of the battery. Never use or combine regular batteries with rechargeable batteries in this Illuminator. Keep batteries away from children.

**WARRANTY:****30-DAY MONEY BACK GUARANTEE**

Risk free purchasing! Laser Aiming Systems Corporation has a 30 day money back guarantee with all product purchases bought from our website. Simply return the product(s), for any reason, within 30 days from your receipt of the shipped product for a full refund of the purchase price. Please contact us to get an RMA number, then pack the item securely in its original box and return ship to:

Viridian  
Returns Department  
5475 Pioneer Creek Dr.  
Maple Plain, MN 55359

Be sure to include with the item a copy of your order number, RMA number, billing name, and address (or simply include a copy of the original invoice.) All products must be returned in good condition, in original boxes, and with all parts and accessories to insure full credit. You will be refunded the shipping cost if the return is a result of a manufacturer error or a shipping error on our part. We recommend using a carrier that provides a tracking number; including insurance on the package is at the shipper's discretion. Viridian is not liable for lost or damaged packages. For warranty questions or servicing of your product, please call 800-990-9390.

**1 YEAR LIMITED WARRANTY**

Viridian® warranties for 1 year after purchase that its Illuminator products will be free from defects in material and workmanship. Viridian® will repair or replace, at its option, any product or part (with the exception of the battery) which is found to be defective under normal use and service, without charge. Viridian's obligation to repair or replace, at Viridian's option, shall be the purchaser's sole and exclusive remedy under this warranty.

Disassembly, modification or otherwise opening up the housing of the unit or any product misuse by the customer voids the warranty. Warranty does not apply to damage due to accident or natural disaster. Warranty does not extend to battery leakage, depletion or decline in performance due to normal aging or to battery issues caused by misuse. See battery specifications, operational instructions and warnings in manual available at [www.ViridianWeaponTech.com](http://www.ViridianWeaponTech.com). This warranty extends only to the original owner and only to CURRENT products listed on the website. Warranty does not apply to discontinued or closeout items. THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN AS SET FORTH ON THIS PAGE, AND LASER AIMING SYSTEMS CORPORATION DISCLAIMS ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. LASER AIMING SYSTEMS CORPORATION SHALL NOT BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH PRODUCT USE OR PERFORMANCE.

For repair or exchange, we require that you send your non-working product to us. Please call or email to receive an RMA number along with a prepaid shipping label. In your package please include of copy of the sales receipt along with any other information needed.